

Instructions:

Double Session housing for Fuel Helmet




Funjump Rigging
1305 N H St
STE A114
Lompoc, CA 93436
678-357-5828
sales@funjump.com



Step 1: Remove the cover from the top mount on your Fuel Helmet. Set the cover and its four screws aside for safe keeping



Step 2: Clean the mount surface of your helmet with alcohol and wait for it to dry



Step 3: There's a thread routed under the adhesive backing on your new double Session housing. Pull up on this thread to help remove those backings.



Step 4: Center the housing over the helmet's top mounting socket and push it into place. Add moderate pressure for about 30 seconds to aid the adhesive's bond.



Step 5: Back the thumb crew out approximately $\frac{1}{2}$ ". It doesn't need to be completely removed.

You can press on the small tab at the bottom left of the back cover to help push it out.



Step 6: Insert the cameras. They can start at a downward angle to avoid contact with the helmet surface, but after about $\frac{1}{2}$ " of insertion they need to go straight in.

If the back button activates, just leave it for 5 seconds and the screen will deactivate.



Note: The spring-loaded lever activates the Session's Record button when this camera is inserted upside down.

You can rotate this camera 90 degrees for a portrait style orientation.



Step 8: Reinsert the back cover, then tighten the thumb screw completely.

Test the back cover to verify that it's locked in place. It should have slight movement or play side to side, but should feel locked in place.

WARNING! Funjump Rigging has made every attempt to build their products to be as safe as possible. However Funjump Rigging, their dealers, and employees cannot be held responsible for injuries, losses, or death occurring through proper or improper use of their product. At the moment of use, the user accepts full responsibility for their own well-being and property with full knowledge of the risks involved in their activities.