

# **HYPOXIC'S OPTIMA INDICATOR**

## **Bright, Reliable, LED Indicator for L&B's *Optima* and the *Optima II Led Visual Warning Model* Audible Altimeters**

Thank you for purchasing Hypoxic's Optima Indicator. This indicator is meant to be used with the LARSEN & BRUSGAARD's *Optima* and the *Optima II Led Visual Warning Model* and is no way endorsed by LARSEN & BRUSGAARD.

---

**Warning: PARACHUTING IS A HAZARDOUS ACTIVITY THAT CAN RESULT IN INJURY OR DEATH.**

**Hypoxic's Optima Indicator is intended to be a backup device and must not be relied upon as your primary means of maintaining altitude awareness. Use Hypoxic's Optima Indicator at your own risk!**

---

### **Waiver of Liability**

The buyer and user of "Hypoxic's Optima LED Indicator" indemnify the manufacturer and vendor from any liability for damage incurred before, during and after skydiving with the instrument. This device subject to malfunction, even when properly designed, built, assembled, maintained, and used.

### **Six (6) Months Limited Warranty**

Get Hypoxic LLC (HYPOXIC) warrants this HYPOXIC-branded hardware product against defects in materials and workmanship under normal use for a period of SIX (6) MONTHS from the date of retail purchase by the original end-user purchaser. At our digression we will either replace, repair, or provide user replaceable parts to fix the unit.

#### **EXCLUSIONS AND LIMITATIONS**

HYPOXIC does not warrant that the operation of the product will be uninterrupted or error-free. HYPOXIC is not responsible for damage arising from failure to follow instructions relating to the product's use.

This warranty does not apply: (a) to damage caused by or to non-HYPOXIC products; (b) to damage caused by accident, abuse, misuse, flood, fire, or other external causes; (c) to damage caused by improper installation or improper handling.

#### **OBTAINING WARRANTY SERVICE**

The customer must contact HYPOXIC via email at [support@gethypoxic.com](mailto:support@gethypoxic.com) to receive approval for Warranty Service. At that time, HYPOXIC will provide the customer instructions on how and if warranty service with be provided.

## Installation Usage & Testing

For reliable usage and long life span you must follow these instructions!

Skydiving causes extreme strain on cables left into the windstream. Care must be taken to ensure the product does not “flap in the wind.” Also, do not yank or pull on the cable while installing the unit or putting on the helmet. **This is potentially a life saving device, treat accordingly!**

This device was designed to be mounted above or to the side of your eye and not directly in front. It's best to temporarily mount the indicator and then test out the Optima to determine the best and brightest mounting position.



YES: Correct Mounting: - Above Eye and supported by helmet



NO: Incorrect Mounting: - In Front of Eye



**NO:** Incorrect Mounting: - LED flapping in wind

### Connecting and Testing

To connect the Hypoxic Optima Indicator, firmly seat the MMCX connector of the indicator into the female port on the side of the Optima or Optima Led Visual Warning Model.



To test the indicator out, simply go into the setup of the Optima and select the ear icon. ))) 3  
The Optima will emit, 3 test sets each corresponding with the 3 freefall alarms. The indicator should flash during all three of these. If you do not know how to go through the Optima menu system, please see the section labeled "Test Alarm Sounds" in the Owner's Manual.

If you have any questions on the usage of this product, please feel free to contact us at [support@gethypoxic.com](mailto:support@gethypoxic.com)

